

# LASER BORE SIGHT MANUAL

(EXTERNAL BATTERY BOX)

FINALLY FROM THE #1 NAME IN LASERS, AIMSHOT, COMES A SIMPLE, EASY AND INEXPENSIVE WAY TO ACCURATELY BORE SIGHT YOUR WEAPON. BY UTILIZING ONE OF OUR LASER BORE SIGHTS (WHERE THE LASER DIODE IS HOUSED) IN CONJUNCTION WITH A CORRESPONDING ARBOR (WHEN APPROPRIATE), YOU CAN SIGHT IN VIRTUALLY ANY WEAPON. THE AIMSHOT BORE SIGHT IS MANUFACTURED IN ACCORDANCE TO THE HIGHEST MILITARY AND INDUSTRY STANDARDS WITH THE LATEST CUTTING EDGE TECHNOLOGY.

## BORE SIGHTING YOUR WEAPON:

THE LASER BORE SIGHT IS FACTORY ALIGNED FOR SIMPLE OPERATION. FIRST, REMOVE THE SMALL SCREWS THAT HOLD THE BATTERY COVER IN PLACE. INSERT TWO AAA BATTERIES (INCLUDED) IN THE PROPER ORIENTATION. THEN REPLACE THE BATTERY CAP AND SCREWS. SLIDE THE SWITCH ON THE BOTTOM OF THE BOX TO TURN THE UNIT ON. PLACE THE BORE SIGHT INTO THE WEAPON'S CHAMBER (ALWAYS MAINTAIN LASER SAFETY RULES) USING THE CORRECT ARBOR (IF NECESSARY) FOR THE CALIBER TO BE SIGHTED. IT IS USUALLY NOT NECESSARY TO HAVE THE BOLT CLOSED AS THE BORE SIGHT FITS SNUG IN THE CHAMBER. MAKE SURE THAT THE BOLT CAN NOT SLAM CLOSED ON THE BORE SIGHT AS IT WILL CUT THE WIRE!

MEASURE 25 YARDS. YOU MAY WANT TO USE A VICE OR GUN REST TO ASSIST IN HOLDING YOUR WEAPON ON TARGET. WHILE THE LASER IS ON THE BULLS EYE, YOU CAN NOW OBSERVE HOW MANY INCHES YOUR SCOPE OR IRON SIGHTS ARE OFF TARGET (THE LASER SIGHT WILL PUT YOU WITHIN 1.5" TO 2" INCHES OF DEAD CENTER). DUE TO THE FACT THAT SCOPES VARY, YOU MUST FOLLOW INSTRUCTIONS FOR YOUR PARTICULAR SCOPE TO ADJUST THE CROSS HAIRS TO THE LASER. IT IS NOT NECESSARY TO CALCULATE THE EXACT NUMBER OF CLICKS. YOU MAY SIMPLY CLICK THE RETICLE UP OR DOWN, LEFT OR RIGHT UNTIL IT IS ON THE BULLS EYE WITH THE LASER DOT. THE SAME PROCEDURE IS USED FOR IRON SIGHTS. REMOVE THE BORE SIGHT AFTER SIGHTING YOUR WEAPON (IF THE BORE SIGHT STICKS IN THE CHAMBER, A CLEANING ROD MAY BE USED TO LIGHTLY TAP THE SIGHT OUT OF THE CHAMBER). TURN THE SWITCH OFF ON THE BASE OF THE BORE SIGHT BATTERY BOX TO TURN OFF THE LASER. DO NOT LEAVE THE LASER ON LONGER THAN NECESSARY AS IT COULD CAUSE THE MODULE TO OVERHEAT AND DAMAGE THE LASER MODULE.

WE RECOMMEND REMOVING THE BATTERIES FROM THE BORE SIGHT FOR STORAGE. A BATTERY DISCHARGED IN YOUR BORE SIGHT COULD POSSIBLY DESTROY YOUR UNIT.

NOW, YOU ARE READY TO GO TO THE RANGE WITH YOUR WEAPON VIRTUALLY ZEROED! IT IS NECESSARY TO CONFIRM PROPER ALIGNMENT AFTER USING THE AIMSHOT BORE SIGHT (AT THIS TIME THE FINE TUNING ADJUSTMENTS SHOULD BE MADE). ALWAYS REMEMBER BORE SIGHTING IS TO GET YOU ON PAPER. THE AIMSHOT BORE SIGHT WILL PUT YOU WITHIN 2" OF DEAD CENTER DEPENDING UPON CALIBER, AMMUNITION, AND ZERO.


## ARBOR CROSS REFERENCE GUIDE

### PISTOL CALIBER ARBORS FOR USE WITH 30 CARBINE BORE SIGHT

AR38SPEC	38 SPEC / 357
AR40SW	40 S&W
AR44REM	44 REM MAGNUM
AR44SW	44 S&W SPECIAL
AR45ACP	45 ACP
AR45COLT	45 COLT / 45-70

### RIFLE CALIBER ARBORS FOR USE WITH .223 BORE SIGHT

AR12GA	12 GAUGE
AR20GA	20 GAUGE
AR50BMG	50 CAL.
AR22250	22-250
AR243WIN	243 WIN / 7MM-08 / 308 WIN / 260 REM / 256 WIN / 358 WIN / 307 WIN / 7.62X54 / 338 FED 6MM REM / 444 MARLIN / 356 / 7MM SHOOTING TIMES EASTERNER / 7.62x51 / 358 WIN / 8MM MAUSER
AR264WIN	264 WIN / 300 WIN / 300 WEA / 7MM REM MAG / 338 WIN / 340 WEA / 257 WEA / 358 NORMA MAG / 308 NORMA MAG / 7MM SHOOTING TIMES WESTERNER / 338 MAGNUM / 7MM WEA MAG / 338 WIN MAG 270 WEATHERBY / 7MM WEA MAG / 340 WEA MAG 270 WSM / 300 WSM / 338 LM 300 WIN MAG 300 WEATHERBY 300 RSUM / 7MM RUM AR375HH 375 H&H AR3030 30-30 WIN / 32 WIN / 375 WIN / 225 WIN AR3006 30-06 / 25-06 / 270 WIN / 35 WHELEN 338-06 / 280 REM / 300 SAVAGE AR7.62 7.62X39 / 220 SWIFT / 303 BRITISH / 35 REM AR7MMWSM 7MM WSM / 7MM RSM ARBMMREM 8MM REM / 416 REM MAG AR762NATO 7.61x51 NATO




**DANGER**


Laser Radiation - Avoid Direct Eye Exposure

Max Output: <math>\leq 5mW</math>  
Wavelength: 630-660nm  
This product complies with 21 CFR chapter 1, subchapter J Titan USA LLC  
11770 Haynes Bridge Rd Ste 205-336 Alpharetta, GA 30009 U.S.A.  
CLASS IIIa LASER PRODUCT Made in Taiwan

Avoid Exposure Laser Radiation Emitted From This Aperture



For .223, .223 20X, .17HMR, .204 - (3) LR41 Button Cell Batteries  
LR41 equivalent batteries = AG3, 192, 392, SG3, SR41



Avoid Exposure Laser Radiation Emitted From This Aperture

For ALL External Battery Box models - (2) AAA Batteries

**NO ARBORS REQUIRED FOR 22LR, 9MM, 17 HMR, 204, AND 50BMG GREEN LASER BORE SIGHTS**