

FINALLY FROM THE #1 NAME IN LASERS, AIMSHOT, COMES A SIMPLE, EASY AND INEXPENSIVE WAY TO ACCURATELY BORE SIGHT YOUR WEAPON. BY UTILIZING ONE OF OUR LASER BORE SIGHTS (WHERE THE LASER DIODE IS HOUSED) IN CONJUNCTION WITH A CORRESPONDING ARBOR (WHEN APPROPRIATE), YOU CAN SIGHT IN VIRTUALLY ANY WEAPON. THE AIMSHOT BORE SIGHT IS MANUFACTURED IN ACCORDANCE TO THE HIGHEST MILITARY AND INDUSTRY STANDARDS WITH THE LATEST CUTTING EDGE TECHNOLOGY.

BORE SIGHTING YOUR WEAPON:

THE LASER BORE SIGHT IS FACTORY ALIGNED FOR SIMPLE OPERATION. FIRST, REMOVE THE BATTERY CAP AND PLACE THE BATTERIES INTO THE BORE SIGHT HOUSING WITH POSITIVE SIDE INWARDS, THEN REPLACE THE BATTERY CAP AND SCREW ON FIRMLY TO TURN ON THE LASER. PLACE THE BORE SIGHT INTO THE WEAPON'S CHAMBER (ALWAYS MAINTAIN LASER SAFETY RULES) USING THE CORRECT ARBOR (IF NECESSARY) FOR THE CALIBER TO BE SIGHTED. SLOWLY CLOSE THE BOLT (IT IS NOT NECESSARY TO HAVE THE BOLT CLOSED ALL THE WAY IF THE BORE SIGHT FITS SNUG IN THE CHAMBER).

MEASURE 25 YARDS. YOU MAY WANT TO USE A VICE OR GUN REST TO ASSIST IN HOLDING YOUR WEAPON ON TARGET. WHILE THE LASER IS ON THE BULLS EYE, YOU CAN NOW OBSERVE HOW MANY INCHES YOUR SCOPE OR IRON SIGHTS ARE OFF TARGET (THE LASER SIGHT WILL PUT YOU WITHIN 1.5" TO 2" INCHES OF DEAD CENTER). DUE TO THE FACT THAT SCOPES VARY, YOU MUST FOLLOW INSTRUCTIONS FOR YOUR PARTICULAR SCOPE TO ADJUST THE CROSS HAIRS TO THE BULLS EYE. IT IS NOT NECESSARY TO CALCULATE THE EXACT NUMBER OF CLICKS. YOU MAY SIMPLY CLICK THE RETICLE UP OR DOWN, LEFT OR RIGHT UNTIL IT IS ON THE BULLS EYE WITH THE LASER DOT. THE SAME PROCEDURE IS USED FOR IRON SIGHTS. REMOVE THE BORE SIGHT AFTER SIGHTING YOUR WEAPON (IF THE BORE SIGHT STICKS IN THE CHAMBER, A CLEANING ROD MAY BE USED TO LIGHTLY TAP THE SIGHT OUT OF THE CHAMBER). TURN THE BORE SIGHT BATTERY CAP TO COUNTER-CLOCKWISE TO REMOVE THE BATTERIES AND TURN OFF THE LASER.

WE RECOMMEND REMOVING THE BATTERIES FROM THE BORE SIGHT FOR STORAGE. A BATTERY DISCHARGED IN YOUR BORE SIGHT COULD POSSIBLY DESTROY YOUR UNIT.

NOW, YOU ARE READY TO GO TO THE RANGE WITH YOUR WEAPON VIRTUALLY ZEROED! IT IS NECESSARY TO CONFIRM PROPER ALIGNMENT AFTER USING THE AIMSHOT BORE SIGHT (AT THIS TIME THE FINE TUNING ADJUSTMENTS SHOULD BE MADE). ALWAYS REMEMBER BORE SIGHTING IS TO GET YOU ON PAPER. THE AIMSHOT BORE SIGHT WILL PUT YOU WITHIN 2-3" OF DEAD CENTER.

DO NOT DRY FIRE. DRY FIRING WILL VOID THE WARRANTY.

DO NOT REMOVE BATTERY BOX BORE SIGHTS BY PULLING ON THE WIRE, USE CLEANING ROD IF NEEDED


ARBOR CROSS REFERENCE GUIDE

PISTOL CALIBER ARBORS FOR USE WITH 30 CARBINE BORE SIGHT

AR38SPEC	38 SPEC / 357
AR40SW	40 S&W
AR44REM	44 REM MAGNUM
AR44SW	44 S&W SPECIAL
AR45ACP	45 ACP
AR45COLT	45 COLT / 45-70

RIFLE CALIBER ARBORS FOR USE WITH .223 BORE SIGHT

AR12GA	12 GAUGE
AR20GA	20 GAUGE
AR50BMG	50 CAL.
AR22250	22-250
AR243WIN	243 WIN / 7MM-08 / 308 WIN / 260 REM / 256 WIN / 358 WIN / 307 WIN / 7.62X54 / 338 FED 6MM REM / 444 MARLIN / 356 / 7MM SHOOTING TIMES EASTERNER / 7.62X51 / 358 WIN / 8MM MAUSER
AR264WIN	264 WIN / 300 WIN / 300 WEA / 7MM REM MAG / 338 WIN / 340 WEA / 257 WEA / 358 NORMA MAG / 308 NORMA MAG / 7MM SHOOTING TIMES WESTERNER / 338 MAGNUM / 7MM WEA MAG / 338 WIN MAG 270 WEATHERBY / 7MM WEA MAG / 340 WEA MAG 270 WSM / 300 WSM
AR270WEA	300 WIN MAG
AR270WSM	300 WEATHERBY
AR300WIN	300 RSUM / 7MM RUM
AR300WEA	375 H&H
AR300RSUM	30-30 WIN / 32 WIN / 375 WIN / 225 WIN
AR375HH	30-06 / 25-06 / 270 WIN / 35 WHELEN 338-06 / 280 REM / 300 SAVAGE
AR3030	7.62X39 / 220 SWIFT / 303 BRITISH
AR3006	7MM WSM / 7MM RSM
AR7.62	8MM REM / 416 REM MAG
AR7MMWSM	7.61X51 NATO
ARBMMREM	
AR762NATO	



NO ARBORS REQUIRED FOR 22LR, 9MM, 17 HMR, 204, AND 50BMG GREEN LASER BORE SIGHTS